

Installation and Mounting Manual

Shenzhen, Guangdong, China · daiwtong824@outlook.com · WhatsApp +852 5966 5756 · sphere-ball.com

Mounting Options

Free standing	Directly on lawn, gravel or paving
Base plate	Square stainless plate made to your fixing centres
Support post	Post and plate for fountain and elevated mounting
Granite or steel base	Sphere mounted on a prepared plinth

Fountain Pipework

An inner pipe runs through the hollow ball with a funnel shaped ending at the top. This gives an even flow of water from the top of the sphere so it runs gently over the whole mirror surface. The pipe exits at the bottom and regularly has a further 10 inch length extending out, attached to a square stainless base plate. Pipe lengths and base plate sizes are custom built to your basin.

Cleaning After Handover

Daily cleaning uses warm water and a cloth, and the surface should be dried with a towel or cloth afterwards because minerals in water leave marks on stainless steel. A mild neutral cleaning agent with warm water removes tough dirt without damaging the surface; rinse thoroughly so no residue is left. Glass cleaner with a microfibre cloth removes fingerprints. Never scrub a polished surface with a steel wire ball, because it leaves scratches that cannot be removed.

All figures are production capability ranges. Confirm the specification for your piece before ordering. Maoping Sculpture Arts does not publish certification claims; ask us what documentation we can supply for your project.