

Solar Wall Light

User Manual



RoHS

PARAMETER


A. Light Control Function


Material	ABS,PC
Solar Panel	2V 0.5W
Battery	AA / 1.2V / 800mAh / NI-MH
LED Source	5 leds
Solar Charging Time	6H
Working Time	>8H
Switch Function	Use the needle to insert the switch hole on the back of the product to turn on

B. PIR Motion Sensor (3 in 1 lighting modes)

Material	ABS,PC
Solar Panel	5V 0.5W
Battery	14500 / 3.7V / 800mAh / Li-ion
LED Source	8 leds
Solar Charging Time	6H
Working Time	>8H
Switch Function	Use the needle to insert the switch hole on the back of the product to turn on
Light Mode (use the needle to insert the switch to change difference lighting modes)	Mode 1(dim light) : Motion Sensor+Dim Light Mode 2(light flashes 2times) : Motion Sensor Mode 3(light flashes 3times) : Always on lighting(without motion sensor)


OVERVIEW






INSTALLATION AND OPERATION INSTRUCTIONS:

Install it by screws



(Remark:if you install on the wooden that not need use the plastic expansion pipe)

Install it by double sided tape



ATTENTION

- (1).Please keep the surface of solar panel clean to ensure it gets enough sunlight
- (2).Keep away from fire source,otherwise the battery would be exploded
- (3).Avoid high temperature,humidity and corrosive environment, otherwise parts would be damaged
- (4).Waterproof in rainy and wet conditions, but please don't dip it intentionally in water
- (5).Before using it for the first time, please turn on the switch and put it in a sunny place to charge for 6-8 hours
- (6).If there any problem with this product,please feel free to contact us to solve it